



Speaker Installation Guide


BDV-HZ970W

© 2010 Sony Corporation Printed in Malaysia

Assembling the front speakers


Required parts

A




×2
Front speaker (R):
with red colored tube
Front speaker (L):
with white colored tube

B




×2

C




×2

D




×2

E




×2

F




×8


- 1** Thread the speaker cord **(A)** through the bottom hole in the base **(B)**.




- 2** Thread the speaker cord **(A)** into the bottom of the post **(C or D)** and out the opposite end.
You can choose either the long posts **(C)** or the short posts **(D)** to assemble the speakers.




- 3** Thread the speaker cord **(A)** through the hole on the bottom of the speaker **(E)** and out the hole on the rear.




- 4** Insert the post **(C or D)** into the hole on the bottom of the speaker **(E)**, so that the screw on the top of the post faces the front of the speaker.



- 5** Secure the post **(C or D)** with the screws **(F)**.




- 6** Connect the speaker cord **(A)**. Then, secure the speaker cord by running it through the slit.
Connect the speaker cord with the colored tube to \oplus , and the speaker cord without the colored tube to \ominus .




Note
Match the color of the tube and label.


7 Insert the post (C or D) so that the slot on the lower post aligns with the projection of the base (B), then secure the post with the screws (F).



1 Connect the speaker cord to the subwoofer.




2 Thread the speaker cord through the gap along the side of the subwoofer, and secure it in the speaker cord holder.




Connecting the speaker cord to the center speaker and surround speakers

Required parts



×3
Center speaker:
with green colored tube
Surround speaker (R):
with gray colored tube
Surround speaker (L):
with blue colored tube


Connect the speaker cord with the colored tube to ⊕, and the speaker cord without the colored tube to ⊖.



Note
Match the color of the tube and the label on the speaker. The label is located at the rear of the speaker.

Connecting the speaker cord to the subwoofer

Required parts



×1
Subwoofer:
with purple colored tube